



205 Westwood Ave, Long Branch, NJ 07740 Touchboards Phone: 866-94 BOARDS (26273) / (732)-222-1511 | Fax: (732)-222-7088 E-mail: sales@touchboards.com | Site: www.touchboards.com 205 Westwood Ave, Long Branch, NJ 07740 E-mail: sales@touchboards.com | Site: www.touchboards.com



Track Technology Systems, Inc.





Made in the U.S.A Patent Pending

## **Table of Contents**

Introduction

# Diversitrack<sup>™</sup> a moving classroom experience

#### 

General Mounting Guidelines	5
Hardware Included	
Carriage Upright	7
Track Frame Layed Out	8

Installation	
Installing Rollers	
Cross Connector Assembly	
Attaching Clips	
Preparing for Tracks Installation	12
Aligning Assembled Frame	
Upper Right Track Installation	
Positioning of Bottom Track	
Lower Right Track Installation	
Level Checking	
Connecting Tracks	
Configuration	
Completing installation	19
Optional Accessories	20
Product Disclaimer	
Product Warranty	22



#### 5

## **General Mounting Guidelines**

#### Tools

Pictured to the right are the basic tools required for Diversitrack installation:

- Level
- Two 11/16" wrenches
- 7/16" wrench
- Phillips screwdriver

If available, ratcheting socket wrenches will expedite assembly.

#### Wall Fasteners

Because of the various wall mounting surfaces, fasteners and/or anchors and inserts are not included to mount tracks to wall.

#### We suggest the following:

- Dry Wall molly anchor or toggle bolt
- Dry Wall/metal stud fine thread sheet metal screw
- Cinder block/brick Tapcon screw



# Hardware Included

# Diversitrack a moving classroom experience






#### **Smaller Parts**





**Carriage Bolts** 



Carriage Upright


# Diversitrack<sup>™</sup> a moving classroom experience


Carant Paris



Track Frame Layed Out

8





**REPEAT ABOVE PROCEDURES FOR ALL FOUR CORNERS.** 




#### Attach end of Cross Connector From underside of Carriage Upright STEP 2 with provided carriage bolt and nut. install serrated hex nut and tighten. Insert carriage bolt from the front side. Carriage Upright 0 0 0 Carriage Cross Connectors Hex Nut **Carriage Bolt** Carriage Upright **Carriage Bolt**

**REPEAT ABOVE PROCEDURES FOR ALL FOUR CORNERS.** 

10

**Cross Connector Assembly** 





# Diversitrack

#### Diversitrack a moving classroom experience

#### **Preparing For Track Installation**

#### Preparation for Diversitrack Track Section Installation.





STEP 3 At the point of installation, mark the target of your projected image space where you wish your interactive white board to be used.

**NOTE:** in this example, we have chosen a *left-hand slide*. Simply reverse this if you want **Diversitrack** to slide out of the way to the right.




#### Aligning Assembled Frame

STEP 1 Locate your assembled Diversitrack frame and trial-fit/rest the top rollers on the top frame of your dry erase or chalk board.

**STEP 2** Position the frame as close as possible to the center of your projected image space.

13

Mark your lines on this side for a <u>left-hand</u> slide.



desired track positioning.


#### Upper Right Track Installation


## Diversitrack a moving classroom experience

**STEP 1** Remove the frame and set it aside. You are now ready to attach the upper right track section.

14

- STEP 2 If you choose to mount Diversitrack up higher, as depicted here, be sure to use two or more identical shims to properly position and make sure it is level.
- STEP 3 If instead you install it resting on the top of your existing dry erase or chalk board frame, first make sure the stop pin is installed.






In either case, position the end of the track with your line and fasten securely using your choice of fasteners appropriate for your environment.


# Diversitrack a moving classroom experience

15

#### Positioning of Bottom Track

- STEP 1 Once again, locate your frame assembly and slide the top two rollers into the upper right track from the side/open end.
- TEP 2 Now slide the frame assembly all the way over and against the stop pin. This will assist in our next step, positioning the first bottom track section.






# 16


#### Lower Right Track Installation

## Diversitrack a moving classroom experience

- STEP 1 Now install the LOWER right track section. Locate another track section and be sure to install the stop pin.
- STEP 2 While holding this section at an angle, slip the bottom rollers into the groove and position the track section against the wall making sure the end lines up with our mark.

- In all cases, be sure that after installing a track section that the rollers make contact with the bottom groove!
- You will want to double check the top as well and may want to get a helping hand to hold the frame firmly in place while doing so.








**Connecting Tracks** 

Next, complete the installation of the two left track sections.


In our example below, our dry erase board doesn't extend to the left as far as a normal classroom.

We again used a level to assure proper placement. Simply place the left track section against the right and fasten to the wall.



19 Completing Installation	<b>Diversitrack</b> <i>a moving classroom experience</i>
STEP 1As with the right side, move the frame over to the left to assistSTEP 8in installing the bottom left track section.	Push the top of your interactive whiteboard up and against the top of the Diversitrack frame. You are now ready to install the top clips.
STEP 2Once again, install the stop pin on the left side of the track, tilt the track and drop the rollers into the groove.STEP 9	Line up the bolt with the hole in the Carriage Upright, insert the bolt through
STEP 3 Check that it is level and fasten to the wall. The system is now installed!	the hole and fasten with the serrated flange nut. Once the top clips are in place, be sure to tighten the flange nuts securely behind ALL FOUR clips.
STEP 4 Move the frame the entire length to ensure ease of operation. You are now ready to place your interactive whiteboard in the frame.	
STEP 5 Position the board evenly in the center and rest the bottom in the two clips you installed at first.	
<b>STEP 6</b> First, insert the carriage bolt from the inside of the clip matching up with the rectangular notch. The bolt will point back toward the wall.	


**STEP 7** Slide these clips down and over the top frame of your interactive whiteboard directly in line with the Carriage Upright.



Your installation of Diversitrack is complete!

#### **Optional Accessories**





**Wall Mount Projector Plate** 

20

**Projector Box Enclosure** 

Universal Box Enclosure for Hitachi A100, Epson & all others.