



1.0" MINIMUM RECOMMENDED DISTANCE, TABLE EDGE TO WIRING CHANNEL

IF DESIRED, REMOVE LINER FROM ADHESIVE STRIPS TO HOLD CHANNEL IN PLACE WHILE INSTALLING SCREWS

INSTALL SUPPLIED SCREWS THROUGH MOUNTING FLANGE INTO BOTTOM SURFACE OF DESK / TABLE / COUNTER, 1/2" FROM ENDS, MIN., RECOMMENDED, AND AT MIDDLE OF CHANNEL

TO SHORTEN OR OTHERWISE CUT WIRING CHANNEL, IT'S RECOMMENDED THAT A HACK SAW WITH A FINE-TOOTHED BLADE BE USED, FOR BEST RESULTS.



205 Westwood Ave, Long Branch, NJ 07740
Phone: 866-94 BOARDS (26273) / (732)-222-1511
Fax: (732)-222-7088 | E-mail: sales@touchboards.com