

FSR SW-WT-RC Installation Instructions

244 Bergen Boulevard, Woodland Park, NJ 07424, Phone: 973.785.4347 - Fax: 973.785.4207

NOTICE: For installation by a qualified electrician in accordance with all national and local electrical codes and communications standards. Adhere to the following instructions and any instructions included with the individual raceway components.

1. Layout Smart-Way system and determine box location.
2. Insert box tabs to wall raceway then install and tighten set screws in tabs.
3. Secure box and raceway base to wall with hardware (by others) as required.
4. Install high-voltage wiring as necessary and allowed. Run high-voltage wiring into either side channel of the raceway base desired - the center channel is reserved for low-voltage wiring.
5. If any low-voltage/data/audio/video wiring is to be installed, pull and run such wiring thru the center opening of the box chasses into the center channel of the raceway base.
6. After system has been completely wired, install wall mounted raceway cover.
7. Slip the box cover down into place over the box chassis, ensuring the cover is seated on the chassis properly, then tighten the (2) screws to secure the cover to the chassis.

CAUTION: Ensure Edge Of Raceway Cover Is Deburred.

