



One Touch Freestanding Assembly Instructions




WARNING: Never operate unit with more than two monitors without securing the unit to the desk. The unit could possibly tip over causing bodily injury or product damage.

Slatwall units (model numbers containing -S and -SFCG) must be installed on a slatwall or in front of a wall/panel, not on an open desk.

Included Parts:



Additional Parts Included with Dual Bundle ONLY:



Step 1: Lay unit down face up on a solid, sturdy hard surface. Use provided allen key (A) to loosen the four 6mm allen screws that come pre-assembled on the underside of the lift assembly.



Step 2: Slide the legs (E) on the lift assembly (D), making sure rubber pads are on the underside of the legs and the base of the lift assembly, where they will be touching the desk in the upright position.



Step 3: Re-tighten the screws at the base of the unit to secure the legs to the base.



Step 4: Loosen the screws in the middle of the worksurface support brackets as shown here. These screws may be loosened with the included #5 allen key or by hand based on preference.



Step 5: Slide the upper worksurface (F) into the support brackets as shown:



PLEASE NOTE:

Make sure to fully insert into brackets into the slots as far as they can go. There are small screw stops in place that will stop the worksurface once it has reached its correct position.




Step 6: Hand tighten the thumb screws fully to secure the worksurface into place.




Step 7: Turn unit upright to standing position on desk or hard surface for the remaining installation steps.

Step 8: Align t-nuts to parallel on L bracket (J).



Step 9: Slide L bracket onto base unit, allow L brackets to drop down to worksurface.



Step 10: Tighten bolts with 5mm hex key.




Step 11: Route the cables from the switch (G) through the opening in the upper worksurface.




Step 12: Attach the switch to the upper worksurface with the two Phillips head screws (H).



Step 13: Plug the connector from the switch located on the top worksurface to the port on the left side of the actuator motor as shown below.



Step 14: Route the power cable (C) coming from the actuator motor out the back of the unit through the notch in the back cover and attach the power cord extension.



Step 15: With the unit placed securely on the desk, lower work surface (I) over brackets.



Step 16: Screw the lower worksurface on to the right angle brackets with the flat head screws (B) and the supplied 4mm allen key.

This concludes installation instructions for the One Touch Freestand unit! Enjoy!

If you have purchased a Freestand Bundle, please continue to follow the remaining installation steps:

Step 17: Slide the monitor arms (K) into the vertical post from the top and use the plastic knobs to secure in place. Leave them flush with the top of the post for a neutral monitor position. Note that these are adjustable to allow a larger range of monitor positions.



Step 18: Attach monitor to pivot (L) using provided Phillips head screws (M).



Step 19: One attached, slide monitor pivot into the pivot pocket located on each arm.



Step 20: Enjoy your new One Touch Freestand Bundle!

