

27736 Mobile 40 Tub Storage Cart



Part Drawing Description Ctn. Qty	Part Drawing Description Ctn. Qty
	Hardware List A Phil Screw M6X15mm 16 EA
P-1 Left Leg Welded * 1 EA	A1 CS Phil Screw M6X50mm 18 EA
P-2 Right Leg Welded * 1 EA	A2 Wood Screw M7x50mm 7 EA
	A3 CS Wd Screw M3x12mm 12 EA
P-3 Slotted End Panel * 2 EA	A4 Phil Pan Screw M4x12mm 4 EA (Door Knobs) A5 Pan Wd Screw M4x18mm 6 EA
P-4 Middle Panel # 1 EA	A6 Socket Screw M6x65mm 4 EA
P-5 Top Panel # 1 EA	A7 Small CS Screw 2 EA
P-6 Bottom Panel # 1 EA	C1 Cam Lock 2 EA
	C2 Cam Post 2 EA
P-7 Back Panel # 1 EA	D Locking Caster 2 EA
P-8 Shelf *# 9 EA	E Non-Locking Caster 2 EA
P-9 Left Door # 1 EA	F Door Handle 2 EA
P-10 Right Door # 1 EA	G Wood Dowel 1 EA
P-11 Caster Base * 1 EA	H Magnet * 2 EA
	I





NOTE: 27736 Mobile 40 Tub Storage Cart comes in two boxes


58468 Box 1 = # 58469 Box 2 = *


Assembly Diagram

To Assemble:










- 9. Place Slotted End Panel (P3) over the end of 9 Shelves (P8) as shown in illustration #6.
- Attach Left Leg Welded (P1) to the Top and bottom Panels (P5 & P6) using 6 CS Phil Screws (A1).

13. Place the Left Door (P9) with the Predrilled (for Hinges) holes facing up and Insert 1 each Lock Cylinder (K1) through the hole in the Left Door (P9) as shown in illustration # 7. Secure Lock Cylinder (K1) using the Lock Washer (K2) and the Lock Hex (K3). (FINGER TIGHTEN ONLY.)



- 16. Place the Right Door (P10) with the Predrilled holes facing up and Insert 1 each Lock Cylinder (K1) through the hole in the Right Door (P10). Secure Lock Cylinder (K1) using the Lock Washer (K2) and the Lock Hex (K3). (FINGER TIGHTEN ONLY.)
- 17. Slide Lock Retainer (K4) over the square end of Lock Cylinder (K1). Secure using the ¼" Phil Head Lock Screw (K5).






Illustration #8


18. Attach 1 Door Handle (F) to the Right Door (P10) using 2 Screws (A4).



- 23. Attach Left Door (P9) to Left Leg welded (P1) using 6 screw (A3) as shown in illustration #11 and Detail #11A.
- 24. Attach Lock Catch (J) to Middle Panel (P4) using 2 screw (A5). See Detail #15A.
- 25. Attach Right Door (P10) to Right Leg Welded (P2) using 6 screw (A3) as shown in illustration #12 &12A.
- 26. Before tightening the Lock Hex (K3) on either door, insert the Key (L) and turn lock. Be sure that Lock Retainer (K4) turns 90 degrees and rotates behind Door Stop (J).

 TIGHTEN LOCK HEX (K3). SEE ILLUSTRATION # 7 & # 8.





27. Attach Magnet (H) on the back at the top of each Leg Weld assembly using two Screws (A5) and into the punched holes. Attach a Metal Plate (I) to the front of each Door using a CS Screw (A7) as shown in illustration #13.




Illustration # 13

27736 Mobile 40 Tub Storage Cart

