

with all electric drill, driver extension, and #11 minups driver, attach each folding bracket to the support brack with (3) #8 x 1/2" PHSM screws. Tighten securely, but be careful not to strip out the holes. **Figure 2**.



3. Attach shelf to folding brackets

- A. With the folding brackets in the "UP" position, set the shelf on the brackets and align the mounting holes.
 B. Attach the shelf to the each folding bracket with (4) #8 x 3/4" PHSM screws and tighten securely with a Phillips screwdriver. Figure 3.
- C. Install the 2" grommet.
- D. Lower shelf (see instructions below.)
- E. With the shelf in the lowered position, tighten the previously installed JC bolts securely.

