# **Assembly Instructions**

#### ▲ Important ▲


Before you begin, read and comply with all safety and operating instructions, and ensure all parts and correct quantities are included.

Any parts damaged during shipment must be reported within 5 days of receipt. To report information regarding missing parts or damage, to purchase parts or accessories, or if you have any questions, please contact us.

#### www.spectrumfurniture.com

800-235-1262, 715-723-6750

Thank you for purchasing Spectrum products!




(1) 0147901 Tray



(2) 0142528 Bar support (with threaded weld studs)





#### **Accessory Shelf** 55515

#### Hardware



(2) 042749 #8 x 1" PHSM





## Assemble bar supports

1. The bars should be assembled with the tabs facing away from each other as shown in Figure 1.

- 2. Loosen the (2) wingnuts slightly.
- 3. Repeat for the 2nd set of bars.



SPECTRUM INDUSTRIES INC.

Figure 1

### 2 Install bars into cart

- 1. Determine the approximate location (height) you would like the shelf to be mounted. The rear bar is (1) slot higher than the front.
- 2. Insert one tab into a slot in the left slotted upright. Figure 2.
- 3. Insert the opposite tab into the corresponding right slotted upright and fully extend the bar assembly into place.
- Lock the extended position of the bars by <u>securely</u> tightening the (2) wingnuts. <u>Be sure both wingnuts are tight</u>.
- 5. Repeat for the 2nd set of bars.

Note: When determining the location of the shelf, be sure it will clear any obstructions that may be inside the cabinet and enough clearance (height) is provided for all devices.




Figure 2

## 3 Install accessory shelf onto bars

- Carefully set the <u>empty</u> accessory shelf onto both sets of bars. Be sure the rear channel "hooks" the rear set of bars fully. Figure 3.1.
- Install (2) #8 x 1" PHSM screws into the back of the module-this will prevent removal. Figure 3.2.





