

CORNER RADIUS TEMPLATE

Most windows use either a 2.5" or 3" radius. Below is a template to help you determine your radius.

1. Make sure you printed this document out at full scale. This means that the solid black line below should be 6" in diameter (from side to side).
2. Hold this template up to the rough opening for the window and determine which radius most closely matches. This is the radius of your window.

