



# YAKIMA LandingPad #10



**TOOL:**  
**5 mm Allen wrench**  
(included in Control Tower kit)




**Note: Crossbar spread for this vehicle is fixed at 27.5 inches.**




BASE COVER (2X)



BASE (2X)



RUBBER SKIRT (2X)



SPECIAL NUT (4X)

WASHER (4X)

*Refer to YAKIMA Control Tower instructions for important warning and load limitations, and YAKIMA's limited warranty.*

Part #1033434 Rev.A


**1**

*If your vehicle has factory crossbars, remove them now, then proceed to step 3.*


**2**

## REMOVE THE FOUR COVER-PLATES.


*Use a flat tool to pry them off.*



*Access the small depressions on the edges of the plates.*



**REAR**




**FRONT**

**3**


## LOCATE FACTORY STUDS.

*You may want to prepare factory studs by installing and removing special nuts until factory studs are free of paint.*

*Thread on a special nut until you feel resistance, then turn an additional 90°. Remove nut, and blow the nut and stud clean with compressed air. Repeat this process until the nut threads all the way.*

**4**

## Remove the covers from the bases.




*When the racks are not installed, use the covers to keep the bases free of debris.*

**5**


## COMBINE BASES, WITH SKIRTS, INSTALL INTO TRACK.

- Combine bases with skirts.
- Arrows facing toward front of vehicle.


**← FRONT OF VEHICLE**



- Tall side of skirt facing outboard (away from center of vehicle).

**← OUTBOARD**  **OUTBOARD →**


- Install special nuts and washers onto designated studs (refer to Step 3).



**6** Using wrench from Control Tower kit, tighten special nuts completely.



- *Pull rear side of base toward you as you tighten the special nuts as shown.*
- *Make sure bases are fitting tightly into track.*



Tighten Rear first,  
then tighten the front.

**7 READ THESE WARNINGS!**



*Make sure Control Towers, with bars installed, seat completely with Landing Pad. If they do not seat properly, repeat step 6 with special attention to pulling rear side of landing pad toward you as you tighten the special nuts.*



*Be sure all hardware is secured according to instructions. Failure to perform safety checks before driving away can result in property damage, personal injury, or death.*

*Attachment hardware can loosen over time. Check and tighten if necessary, before each use.*



• **DO NOT EXCEED WEIGHT LIMIT:  
165 lbs. (75 kg)**

• **Consult your YAKIMA dealer or fit list to see load limitations for accessories.**

*Remove your YAKIMA rack and accessories before entering automatic car washes.*

**8 Continue with Control Tower installation.**