



Width: 600-1000

FI.PK.BED.222.008 - PEBBLE







(K) x4 30mm Screw

x4 Stick On Cover Cap

(N) x1 Door Buffer



Screws and fixings for attaching to walls are not provided as these vary depending on materials, thickness and construction. Ensure appropriate fixings for wall construction are used.

Step1.

Ensure the units going either side of the knee drawer are level, positioned correctly and fully secured before installing the knee drawer unit. Position the knee drawer unit between the two units.

Align and level the knee drawer with the units so the fronts of all units are straight, level and flush.

Step2.

Secure the knee drawer unit to the side units by screwing from inside the side units through into the knee drawer using 2 x 30mm screws **(K)** on each side. Position one screw at the front and one screw at the rear of the unit. Place stick on cover caps on the heads to conceal them.

