


*Vogue*


 **BASE UNIT**

**500-1000, Sink Hob 1-2 Door / 1-2 Door + Dummy Drw Assembly Guide**


**wren**




**500 1 Dr/ 1Dr + Dummy Drw**




**600 1 Dr/ 1Dr + Dummy Drw**




**600 1 Door Overmount  
Belfast**




**700 2 Door**




**800 2 Door**




**1000 2 Door**


**BEFORE YOU START****INSTALLATION SHOULD BE PERFORMED BY A COMPETENT PERSON ONLY.****THIS PRODUCT COULD BE DANGEROUS IF INCORRECTLY INSTALLED****TWO  
MAN  
JOB****PROTECT  
AGAINST  
DAMAGE****NOT to be used with  
CAM LOCK**




**Panel A**  
x2 End Panel



**Panel B**  
x1 Back Panel  
(800-1000 Folded)




**Panel C**  
x1 Fixed Shelf




**Panel D**  
x1 Rail




**Shelf**  
x1 Loose Shelf




**Rail**  
x1 Metal Rail



**Frontal**  
x1 or 2 as req'd  
(Packed Separately)




**Frontal + Dummy Drawer**  
**(Frontal + Dummy Drw Option)**  
x1 or 2 as req'd  
(Packed Separately)




**(F) x8**  
Wooden  
Dowel




**(L) x26**  
15mm  
Screw




**(K) x8**  
30mm  
Screw




**(G) x6**  
Cam Dowel  
(Expanding)




**(H) x6**  
Cam Lock




**(Z) x4**  
Shelf Peg Metal




**(M) x4**  
Cover Sticker




**(N) x2**  
Door Buffer




**L Bracket**  
x2




**(U) x2**  
Fixing Plate  
Inc Screws





**Leg**






**Hinge**  
Inc Screws & Cover Plate




**Hinge Mounting Plate**  
Inc Screws







Metal Rail  
Insert



Metal Rail  
Insert




**Step 3.**

Attach panel **(C)** & metal rail to panels **(A)** using expanding cam dowels **(G)**, and wooden dowels **(F)** in positions as shown. Secure metal rail with 2 x 15mm screws **(L)** into panels **(A)**.




All cam lock **(H)** holes are to be positioned facing the outside of the unit carcase, for ease of tightening.



**Step 4.**


Slide back panel **(B)** into groove of end panels **(A)**. Once back panel **(B)** is in position, ensure the panel is flush & square with bottom of end panels.

The back panel **(B)** is to be modified accordingly to suit customer requirements, prior to inserting into unit.




## BASE UNIT

## 500-1000, Sink Hob 1-2 Door / 1-2 Door + Dummy Drw Assembly Guide

**Step 5.**


Insert cam locks **(H)** and hand tighten them, this will expand cam dowels **(G)** and tighten the unit together.



Do **not** use power tools with cam lock **(H)**


# BASE UNIT

## 500-1000, Sink Hob 1-2 Door / 1-2 Door + Dummy Drw Assembly Guide



### Step 6.

Ensure the unit is square. Secure back panel **(B)** with 4 x 30mm screws **(K)** equally spaced at the bottom of back panel **(B)** into base panel **(C)**, as shown. Ensure you screw into the centre of the base panel **(C)** (9mm from the edge).







**Step 7.**

Position legs as shown on the diagram below. Ensure legs are rotated to also provide support to the end panels (A). Once positioned, secure each of the legs into place with 4 x 15mm screws (L) per leg. Push leg firmly down into leg base. Adjust legs to **155mm** before turning unit upright. Once in situ level accordingly.

**500-600 width = 4x leg**



**700-1000 width = 5x leg**



**Step 8.**


Attach hinge plates onto both end panels **(A)** as shown, using 2 screws already located in hinge plates.

**Hinge to be mounted in accordance to customer specific kitchen plan.**

**DUMMY DRAWER SPECIFIC**




Screws for attaching to walls and worktops are **not provided** as these vary depending on materials, thickness and construction. Ensure appropriate fixings for wall and worktop construction are used. Please refer to the specialist worktop supplier if these are required for solid surface worktops.




### Step 9.

Ensure the unit is positioned correctly and level. Screw through the back rail into the wall to secure the unit in place.




### Step 10.

Screw into any side units using 30mm screws **(K)** provided to secure to unit. Screw at the top and bottom of both sides of the unit, place cover stickers **(M)** on the heads to conceal them.




### Step 11.

Use 2 x 15mm screws **(L)** to secure each of the L brackets to the top rear of the unit on both sides.



### Step 12.


Screw up through the front metal rail and the L brackets into the worktop to secure it in place.



### FRONTAL AND HINGE ATTACHMENT


#### Dummy Drawer Attachment Only

Align doors to join together using 2 x fixing plates (**U**) to the back of both frontals. Ensure a 4mm gap is maintained between each frontal once fixed together. Screw in place using 4 x 15mm screws (**L**) per fixing plate. Continue to **Step 1** for door frontal attachment.





#### Step 1.

Insert hinges into frontal hinge holes provided, secure hinges with the 2 x screws already located in the hinges.




#### Step 2.

Attach the door to unit, clip hinges onto hinge plates and click to secure.



#### Step 3.

Adjust hinges to suit, using the highlighted screw(s) shown.



#### Step 4.

Fit cover caps to hinges and adjust soft-close to suit.



The top and bottom hinges **MUST** be adjusted to the **SAME STRENGTH**.

Vogue

 **BASE UNIT**

**500-1000, Sink Hob 1-2 Door / 1-2 Door + Dummy Drw Assembly Guide**

**wren**