


Vogue




wren

BASE UNIT


300-600, 1 Door / 1 Door + 1 Drw Assembly Guide




300 1 Dr / 1Dr + 1 Drw




400 1 Dr




450 1 Dr




500 1 Dr / 1Dr + 1 Drw



500 Bin Base Unit
(with lids)




600 1 Dr / 1Dr + 1 Drw



600 Bin Base Unit
(with metal shelf)




NON-DRAWER OPTION SHOWN THROUGHOUT FOR ILLUSTRATION PURPOSES

**BEFORE YOU START****INSTALLATION SHOULD BE PERFORMED BY A COMPETENT PERSON ONLY.****THIS PRODUCT COULD BE DANGEROUS IF INCORRECTLY INSTALLED****TWO
MAN
JOB****PROTECT
AGAINST
DAMAGE****NOT to be used with
CAM LOCK**

DRAWER LINE SPECIFIC

Standard Drawer (Packed Separately)



Drawer Base
x1 Drawer Base Panel

Frontal
x1 Front Panel
(Packed Separately)

Back Panel
x1 Metal Back Panel
(Small)

Drawer Side
x1 Left Hand

Drawer Side
x1 Right Hand

Drawer Runner
x1 Left Hand


Drawer Runner
x1 Right Hand




(J) x16
16mm
Screw




(Q) x4
21mm
Screw



(N) x1
Door Buffer





Drawer Cover Cap
x2




Drawer Front Fixing
x2

DRAWER LINE SPECIFIC**Step 1.**



Seat the edge of drawer base tight into the corner of the drawer side, as shown. The decorative face of drawer base to be positioned at the front of the drawer. Secure drawer base to drawer side using 4 x 16mm screws (**J**) in holes provided. Repeat on both sides of the drawer.

**Step 2.**

Clip metal back panel into the rear of the drawer sides and secure in position using 2 x 16mm screws (**J**) into drawer base in holes provided.

**Step 3.**

Secure **drawer side fixing clips** using 2 x 21mm screws (**Q**) in pilot holes provided on the frontal, as shown. Attach drawer frontal to drawer box by pushing drawer side fixing clips into drawer sides.




DRAWER ADJUSTMENT**Left and Right Adjustment**


Turn screw shown to **adjust** drawer frontal **left & right**.




Drawer adjustments to be done on both sides.

**Up & Down Adjustment**


Turn screw shown to **adjust** drawer frontal **up & down**.

**Lock Position**


Tighten screw shown to lock in position.

**Remove Frontal**

To remove the frontal, release the fixing clip by turning the locking plate screw shown.

**Cover Caps**

Fit drawer cover caps over drawer side adjustment.




Vogue




BASE UNIT

300-600, 1 Door / 1 Door + 1 Drw Assembly Guide


wren




Panel A
x2 End Panel




Panel B
x1 Back Panel




Panel C
x1 Base Panel




Panel D
x2 Rail




Shelf
x1 Loose Shelf




Frontal
x1 Front Panel
(Packed Separately)




(F) x12
Wooden
Dowel




(L) x28
15mm
Screw




(K) x7
30mm
Screw




(G) x8
Cam Dowel
(Expanding)




(H) x8
Cam Lock



Space Plug
x1




L Bracket
x2





(Z) x4
Shelf Peg Metal




(M) x4
Cover Sticker



(N) x1
Door Buffer



Hinge
Inc Screws & Cover Plate







Hinge Mounting Plate
Inc Screws



Step 1. DRAWER LINE SPECIFIC (Skip to Step 2 for non- drawer line option assembly)

To attach drawer runner, screw into end panels (**A**) using 2 x 16mm screws (**J**) (provided with drawer box pack) per drawer rail, into holes provided, as shown.

Repeat **Step 1** for the other end panel (**A**).

Drawer runner bracket screw position






Step 4.

Attach panels **(C)** & **(D)** to panels **(A)**, using expanding cam dowels **(G)**, and wooden dowels **(F)** in positions as shown.



All cam lock **(H)** holes are to be positioned facing the outside of the unit carcase, for ease of tightening.





Step 5.

Slide back panel **(B)** into groove of end panels **(A)**. Once back panel **(B)** is in position, ensure the panel is flush & square with bottom of end panels.


**For the bin installation.**

Back Panel **(B)** should not be installed (Skip Steps 5 & 7).




**Step 6.**


Insert cam locks (H) and hand tighten them, this will expand cam dowels (G) and tighten the unit together.



Do **not** use power tools with cam lock (H)



**Step 7.**

Ensure the unit is square. Secure back panel **(B)** with 3 x 30mm screws **(K)** equally spaced at the bottom of back panel **(B)** into base panel **(C)**, as shown. Ensure you screw into the centre of the base panel **(C)** (9mm from the edge).





Step 8.

Position legs as shown on the diagram below. Ensure legs are rotated to also provide support to the end panels (**A**). Once positioned, secure each of the legs into place with 4 x 15mm screws (**L**) per leg. Push leg firmly down into leg base. Adjust legs to **155mm** before turning unit upright. Once in situ level accordingly.





LEG POSITIONS - UNDERSIDE VIEW



**Step 9.**



Attach hinge plates onto end panel **(A)** as shown, using 2 screws already located in hinge plates.

Hinge side to be mounted in accordance to customer specific kitchen plan.

DRAWER LINE SPECIFIC


**500 & 600 Bin Base Unit**

Please refer to separate instruction included with your bin.

**500 Bin Base Unit****600 Bin Base Unit**




Screws for attaching to walls and worktops are **not provided** as these vary depending on materials, thickness and construction. Ensure appropriate fixings for wall and worktop construction are used. Please refer to the specialist worktop supplier if these are required for solid surface worktops.




Step 10.

Ensure the unit is positioned correctly and level. Drill a pilot hole through the back rail into the wall. Unwind a space plug until it contacts both surfaces. Finally, secure to the wall using an appropriate screw.




Step 11.

Screw into any adjacent units using 30mm screws (**K**) provided to secure to unit. Screw at the top and bottom of both sides of the unit, place cover stickers (**M**) on the heads to conceal them.






Step 12.


Use 2 x 15mm screws (**L**) to secure each of the L brackets to the top rear of the unit on both sides.




Step 13.

Screw up through the front rail and the L brackets into the worktop to secure it in place.

	<p>HINGE ATTACHMENT AND ADJUSTMENT</p> <p>Step 1. Insert hinges into frontal hinge holes provided, secure hinges with the 2 x screws and hinge dowels already located in the hinges.</p> <p> Hinge dowels</p>
	 <p>Step 2. Attach the door to unit, clip hinges onto hinge plates and click to secure.</p>
<p>Step 3. Adjust hinges to suit, using the highlighted screw(s) shown.</p>	



	<p>Step 4. Fit cover caps to hinges and adjust soft-close to suit.</p>
--	---



The top and bottom hinges **MUST** be adjusted to the **SAME STRENGTH**.

wren