



**EXTREME
DUTY**

**Engineered durability,
extreme duty 4x4 performance.**

Application: GMP13300-XPB

Fitting Instructions for Holden Colorado 2016 On

1. Remove tail pipe and muffler assembly from vehicle.
2. Remove the exhaust rubber hangers from the vehicle.
3. Fit replacement exhaust rubber hangers to the vehicle.
4. Fit exhaust temp and O² sensor plugs to the intermediate pipe.
5. Fit the intermediate pipe to the two bolt DPF Flange using two M8 flat washers and two M8x1.25 lock nuts.
6. Fit the muffler/muffler replacement pipe to the intermediate pipe using four M8x1.25x35mm bolts, eight M8 flat washers, tighten m8x1.25 lock nuts finger tight.
7. Fit tail pipe to muffler/muffler replacement pipe using the two lower bolt holes with two M8x1.25x35mm bolts, four M8 flat washers and two M8x1.25 lock nuts, tighten finger tight.
8. Fit muffler support bracket to rubber hangers. Refer Figure 1.
9. Fit two M8x1.25x45mm bolts, four M8 flat washers and two M8x1.25 lock nuts to the upper bolt holes and the support bracket pictured below, tighten finger tight. Refer Figure 1.



Figure 1.

10. Tighten all bolts and nuts from the front to back of vehicle ensuring all flanges are lined up with each other and test for leaks.

NOTE: WE RECOMMEND FITTING THIS PRODUCT EITHER ON A 4 POST HOIST OR ON THE GROUND

ProMan

A ROCK SOLID REPUTATION

70-84 Miller Street, Epping, Victoria 3076
Phone (+61 3) 8401 8500 Facsimile (+61 3) 9401 4869



redbackexhausts.com.au

Issue Date Oct 2017