



**EXTREME
DUTY**

**Engineered durability,
extreme duty 4x4 performance.**

Application:TYP43400-XPB

Fitting Instructions for Prado 120 series with 1KZ-TE

1. Remove rear tail pipe from vehicle.
2. Remove intermediate pipe and muffler assembly from vehicle.
3. Remove engine pipe from vehicle.
4. Fit replacement rubber exhaust hangers.
5. Fit the engine pipe to the turbo outlet using three M10 flat washers and three M10x1.25 lock nuts tighten finger tight.
6. Fit front intermediate pipe to engine pipe with four M8x1.25x35mm bolts, eight M8 washers and tighten M8x1.25 lock nuts bolts finger tight.
7. Fit muffler to front intermediate pipe with four M8x1.25x35mm bolts with eight M8 flat washers tighten M8x1.25 lock nuts finger tight.
8. Fit rear intermediate pipe to muffler with four M8x1.25x35mm bolts, eight M8 flat washers and tighten M8x1.25 lock nuts bolts finger tight.
9. Fit the tail pipe to the rear intermediate pipe using 3" band clamp tighten finger tight.
10. Tighten all bolts and nuts from front to back of the vehicle.
11. Inspect for equal clearance between the floor and the rear cross member and test for leaks. Refer Figure 2.



Figure 2.

NOTE: WE RECOMMEND FITTING THIS PRODUCT EITHER ON A 4 POST HOIST OR ON THE GROUND

ProMan

A ROCK SOLID REPUTATION

70-84 Miller Street, Epping, Victoria 3076
Phone (+61 3) 8401 8500 Facsimile (+61 3) 9401 4869

Issue Date September 2017



redbackexhausts.com.au