



**EXTREME
DUTY**

**Engineered durability,
extreme duty 4x4 performance.**



Application: TYP43800-XPB, TYP43800-XCB

Fitting Instructions for Prado 120 and 150 Series D4D 1KD-FTV

1. Remove rear tail pipe from vehicle.
2. Remove intermediate pipe and muffler assembly from vehicle.
3. Remove engine pipe from vehicle.
4. Remove turbo outlet from the turbo.

NOTE: If fitting this system to a 150 series Prado the stud on the rear heat shield above the rear cross member shown in Figure 1 will need to be shortened to gain sufficient clearance for the rear intermediate pipe.



Figure 1.

5. Fit replacement rubber exhaust hangers.
6. Fit the engine pipe to the turbo using three M8 flat washers and three M8x1.25 lock nuts tighten finger tight.
7. Fit front intermediate pipe to engine pipe with four M8x1.25x35mm bolts, eight M8 washers and tighten M8x1.25 lock nuts bolts finger tight.
8. Fit muffler to front intermediate pipe with four M8x1.25x35mm bolts with eight M8 flat washers tighten M8x1.25 lock nuts finger tight.

ProMan

A ROCK SOLID REPUTATION

70-84 Miller Street, Epping, Victoria 3076
Phone (+61 3) 8401 8500 Facsimile (+61 3) 9401 4869



redbackexhausts.com.au

Issue Date September 2017



**EXTREME
DUTY**

**Engineered durability,
extreme duty 4x4 performance.**



Application: TYP43800-XPB, TYP43800-XCB

9. Fit rear intermediate pipe to muffler with four M8x1.25x35mm bolts, eight M8 flat washers and tighten M8x1.25 lock nuts bolts finger tight.
10. Fit the tail pipe to the rear intermediate pipe using 3" band clamp tighten finger tight.
11. Tighten all bolts and nuts from front to back of the vehicle.
12. Inspect for equal clearance between the floor and the rear cross member and test for leaks. Refer Figure 2.



Figure 2.

NOTE: WE RECOMMEND FITTING THIS PRODUCT EITHER ON A 4 POST HOIST OR ON THE GROUND

ProMan

A ROCK SOLID REPUTATION

70-84 Miller Street, Epping, Victoria 3076
Phone (+61 3) 8401 8500 Facsimile (+61 3) 9401 4869

Issue Date September 2017



redbackexhausts.com.au