



**EXTREME  
DUTY**

**Engineered durability,  
extreme duty 4x4 performance.**



## **Application:TYP44500-XPB**

### **Fitting Instructions for Toyota Land Cruiser 80 Series Wagon**

1. Remove rear tail pipe from vehicle.
2. Remove intermediate pipe from vehicle.
3. Remove engine pipe from vehicle.
4. Fit exhaust hanger bracket to chassis rail. Refer figure 1.



Figure 1.

5. Fit replacement rubber exhaust hangers.
6. Fit separately ordered engine pipe to engine.
7. Fit front intermediate pipe to engine pipe with four M8x1.25x35mm bolts, eight M8 washers and tighten M8x1.25 lock nuts bolts finger tight.
8. Fit muffler to front intermediate pipe with four M8x1.25x35mm bolts with eight M8 flat washers tighten M8x1.25 lock nuts finger tight.
9. Fit rear intermediate pipe to muffler with four M8x1.25x35mm bolts, eight M8 flat washers and tighten M8x1.25 lock nuts bolts finger tight.

**ProMan**

**A ROCK SOLID REPUTATION**

70-84 Miller Street, Epping, Victoria 3076  
Phone (+61 3) 8401 8500 Facsimile (+61 3) 9401 4869

Issue Date September 2017



[redbackexhausts.com.au](http://redbackexhausts.com.au)



**EXTREME  
DUTY**

**Engineered durability,  
extreme duty 4x4 performance.**



## **Application:TYP44500-XPB**

10. Fit intermediate tail pipe to rear intermediate pipe using 3" band clamp tighten finger tight. Refer Figure 3.



Figure 3

11. Fit tail pipe to intermediate tail pipe with four M8x1.25x35mm bolts and eight M8 flat washers tighten M8x1.25 lock nuts finger tight.  
12. Tighten all bolts and nuts from front to back of the vehicle and test for leaks.

**NOTE: WE RECOMMEND FITTING THIS PRODUCT EITHER ON A 4 POST HOIST OR ON THE GROUND**

**ProMan**

**A ROCK SOLID REPUTATION**

70-84 Miller Street, Epping, Victoria 3076  
Phone (+61 3) 8401 8500 Facsimile (+61 3) 9401 4869

Issue Date September 2017



[redbackexhausts.com.au](http://redbackexhausts.com.au)