

MITSUBISHI MAGNA TE-TW SEDAN 04/96 – 09/05

PART NO.

UNT205

1. Remove trim behind the L/H/S tail light.
2. Disconnect the 6 way connector from the tail light.
3. Connect the 6 way connectors on the Towbar Wiring Harness to the corresponding 6 way connectors on the vehicle.
4. Feed the remainder of the Harness down behind the trim and into the boot area.
5. In the spare wheel well, near the spare wheel, locate a grommet.
6. Pierce the grommet in the centre to allow the wiring harness to be fed through the grommet and out under the vehicle.
7. Fit the required socket to the wiring harness and mount the plug to the desired position.
8. Using cable ties secure the wiring harness to meet the required length.
9. Replace the L/H/S trim panel.
10. Test towbar wiring with a trailer testing box.

