

SUBARU FORESTER SF,SG WAGON 08/97 – 02/08
SUBARU IMPREZA G1,G2 SEDAN / WAGON 04/93 – 08/07
SUBARU LIBERTY BC - BH SEDAN / WAGON 10/89 – 08/03
SUBARU OUTBACK BE - BP WAGON 08/96 – 08/09

PART NO.

UNT209

1. In the luggage area remove the retractable cover.
2. Remove floor cover and expose spare wheel.
3. Remove the centre rear trim.
4. Remove the driver's side rear trim to expose the vehicle towbar wiring harness 10 way connector.
5. The 10 way connector will be found at the rear of the vehicle, depending on the model, later models may have the connector behind the centre trim.
6. Attach the wiring harness 10 way connector to the vehicle towbar 10 way connector.
7. Locate the grommet near the air vent in the rear cavity and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out the side of the vehicle.
8. Pull the wiring harness through the grommet to meet the required length.
9. Using cable ties secure the wiring harness to meet the required length.
10. Fit the required socket to the wiring harness and mount the plug to the desired position.
11. Replace the driver's side rear trim.
12. Refit the centre rear trim.
13. Replace the floor cover.
14. Refit the retractable cover.
15. Test towbar wiring with a trailer testing box.

