

HONDA CRV RD SERIES 1 WAGON 10/97 – 11/01

PART NO.

UNT210

1. Remove floor cover and expose spare wheel.
2. Look for the rear speaker on the passenger side and remove speaker cover.
3. Undo screws holding the speaker to the trim panel.
4. Gently remove the speaker to reveal the towbar wiring harness connector, taped to the speaker cable.
5. Feed the whole towbar wiring harness into the inside of the trim via the speaker hole and attach the connector.
6. Feed the remaining wiring harness down the inside of the trim panel and push out underneath the trim.
7. Pull the wiring harness as far down as you can and allow it to lay in the spare wheel well.
8. In the spare wheel well, next to the spare wheel, locate a grommet.
9. Pierce the grommet in the centre to allow the wiring harness to be fed through the grommet and out under the vehicle.
10. Fit the required socket to the wiring harness and mount the plug to the desired position.
11. Replace the speaker back into the side trim panel and secure with original screws.
12. Replace speaker cover and the floor cover.
13. Test towbar wiring with a trailer testing box.

