

HOLDEN APOLLO JM, JP SEDAN / WAGON 02/93 – 06/06
HOLDEN NOVA LG SEDAN / HATCH 10/94 – 08/96
LEXUS ES300 SEDAN 06/92 – 06/08
TOYOTA AVALON SEDAN 06/00 – 06/06
TOYOTA CAMRY SEDAN / WAGON 02/93 – 06/06
TOYOTA COROLLA 100 SERIES SEDAN / HATCH 06/91 – 06/06

PART NO.

UNT214

1. Remove floor cover and expose spare wheel.
2. Remove the drivers side trim panel.
3. Look for the single towbar wiring harness connector and connect to the wiring harness. If you cannot find the connector refer to step 4.
4. For later model Camry's you will need to remove the rear centre trim. the connector is taped to vehicle harness travelling across the back of the car.
5. Look for a suitable grommet to pierce in the boot area.
6. Pierce the grommet in the centre to allow the wiring harness to be fed through the grommet and out under the vehicle.
7. From the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
8. Fit the required socket to the wiring harness and mount the plug to the desired position.
9. Using cable ties secure the wiring harness to meet the required length.
10. Refit centre trim and or the drivers side trim panel.
11. Test towbar wiring with a trailer testing box.

