

Towbar Wiring Harness Fitting Instructions

MITSUBISHI TRITON ME-MK UTE & CAB CHASSIS 12/86 – 07/06

PART NO.
UNT234

- 1. At rear of the vehicle, locate six pin connector on drivers side chassis rail.
- 2. Unplug connector on vehicle and plug in connectors on wire harness provided.
- 3. Route five core cable to trailer socket mounting position. Make sure cable is securely attached using zip ties or similar (not supplied) and maintains a safe distance from heat or sharp edges.

