

HOLDEN RODEO RA UTE & CAB CHASSIS 02/03 – 07/05

PART NO.

UNT240

1. Locate the 6 way Towbar Wiring connector on rear cross member towards the passenger side.
2. Remove the cap/seal and discard.
3. Connect the 6 way connector from the Towbar Wiring Harness.
4. Using cable ties, secure the cable along desired route and the required length.
5. Fit the required socket to the wiring harness and mount the plug to desired position.
6. Test towbar wiring with a trailer testing box.

