

## FORD TERRITORY WAGON 06/04 – ON (Factory Fitted Sensors Only)

PART NO.

**UNT251**

1. Remove rear bumper.
2. Remove rear air located on the Drivers side rear panel low down.
3. Here you will find 2 connectors. 1 has the reverse sensor wiring connected and the other plug is free.
4. Follow the reverse sensor wiring across to the L/H/S to the to the end of the plug.
5. Remove this wire and plugs all the way back to the R/H/S disconnect this harness and discard.
6. Feed the towbar wiring harness up through the hole in the bottom of the rear corner panel.
7. Connect the 2 clear connectors to the corresponding plugs.
8. Take the remaining wire and connector back to the L/H/S and secure cable along the way.
9. Replace the air vent on the Drivers side.
10. Replace rear bumper.
11. Using cable ties secure the wiring harness to meet the required length.
12. Fit the required socket to the wiring harness and mount the plug to the desired position.
13. Test towbar wiring with a trailer testing box.

