

FORD COURIER ALL MODELS 06/85 – 11/06
MAZDA BRAVO ALL MODELS 06/85 – 11/06

PART NO.

UNT255**CAB CHASSIS**

1. Unplug the 6 way connector behind the RHS tail light.
2. Find the plugs on the harness marked RHS and connect into plugs on car from step 1.
3. Follow the same process for the LHS with the remaining two grey plugs.
4. Using cable ties secure the wiring harness to meet the required length.
5. Fit the required socket to the wiring harness and mount the plug to desired position.
6. Test towbar wiring with a trailer testing box.

UTE

1. Remove RHS tail lights.
2. Unplug the 6 way connector behind the RHS tail light.
3. Find the plugs on the harness marked RHS and connect into plugs on car from step 2.
4. Follow the same process for the LHS with the remaining two grey plugs.
5. Using cable ties secure the wiring harness to meet the required length.
6. Refit both taillights following step 1 in reverse.
7. Fit the required socket to the wiring harness and mount the plug to desired position.
8. Test towbar wiring with a trailer testing box.

