

**MITSUBISHI PAJERO NS-NW  
10/06 – ON**

PART NO.

**UNT268**

1. Remove the luggage compartment rear trim by releasing the three fasteners.
2. Remove the driver's side luggage compartment small floor carpet by releasing the fastener.
3. Release the seat belt bolts on the driver's side of the luggage compartment area.
4. Remove the rear luggage compartment driver's side supper trim by sliding the seat belts through the holes in the trim.
5. Remove driver's side rear door sill.
6. Dislodge the luggage compartment driver's side trim. Do not completely remove.  

Before removing this trim slightly pry open to access the power outlet connector, disconnect then remove the trim.
7. From underneath the driver's side of the rear of the vehicle pierce the grommet then feed a trace wire through the hole to attach to the tow bar harness for pulling back through.  

Seal the grommet with a suitable sealant.
8. From inside the vehicle on the rear driver's side luggage compartment area untape the vehicle connector and attach the trailer harness. ( For NT, NW models the correct connector is further forward above the wheel arch )  

Secure the earth terminal to the body panel.

Connect the ecu module to the harness.

Clean the area of body panel to firmly secure the module using the attached double sided tape on the ECU
9. Remove the passenger's side front door seal and front kick panel
10. Remove the panel underneath the glove box, fold back the carpet and remove the foam block under the glove box.
11. Locate the three way connector and the four way connector in the vehicle harness and connect the cabin harness.

Continued over page

MITSUBISHI PAJERO NS-NW  
10/06 – ON

PART NO.

UNT268

12. Locate the battery power terminal to the positive on the battery.

Secure the engine bay harness ring terminal.

13. Gain access to the four way connector at the rear of the head light.

Remove the blanking plug and connect the vehicle harness and engine harness.

Route and secure with cable ties.

14. Secure harness with cable ties, fit appropriate socket then fit the supplied fuse and test trailer functions

15. Refit all removed parts

