

TOYOTA LANDCRUISER 76 SERIES  
WAGON 03/07 – ON  
TOYOTA LANDCRUISER 79 SERIES  
CAB CHASSIS 03/07 – ON

PART NO.
----------

<b>UNT272</b>
---------------

1. The towbar wiring harness 8 way connector will be found behind the rear cross member closer to the R/H/S.
2. This 8 way connector will have a dummy plug (cap) connected to it. Remove and discard.
3. Attach the wiring harness to the connector.
4. Using cable ties secure the wiring harness to meet the required length.
5. Fit the required socket to the wiring harness and mount the plug to the desired position.
6. Test towbar wiring with a trailer testing box.

