



Towbar Wiring Harness Fitting Instructions

SUBARU FORESTER SH,SJ WAGON 03/08 – ON
SUBARU IMPREZA G3,G4 HATCH 09/07 – 01/10
SUBARU IMPREZA G3,G4 SEDAN 09/07 – 01/12
SUBARU LIBERTY MY10 SEDAN & WAGON 09/09 – ON
SUBARU OUTBACK BM,BR WAGON 09/09 – 12/14
SUBARU XV G4-X WAGON

PART NO.

UNT276

FORESTER / LIBERTY WAGON

1. In the luggage area remove the retractable cover.
2. Remove floor cover and expose spare wheel.
3. Remove the centre rear trim.
4. Remove the Passenger side rear trim to expose the vehicle towbar wiring harness 10 way connector.
5. The 10 way connector will be found anywhere from the back seat down to rear of the vehicle, depending on the model.
6. Attach the wiring harness 10 way connector to the vehicle towbar 10 way connector.
7. Locate the grommet near the air vent in the rear cavity and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out the side of the vehicle.
8. Pull the wiring harness through the grommet to meet the required length.
9. Using cable ties secure the wiring harness to meet the required length.
10. Fit the required socket to the wiring harness and mount the plug to the desired position.
11. Replace the Passenger side rear trim.
12. Refit the centre rear trim.
13. Replace the floor cover.
14. Refit the retractable cover.

SUBARU FORESTER SH,SJ WAGON 03/08 – ON
SUBARU IMPREZA G3,G4 HATCH 09/07 – 01/10
SUBARU IMPREZA G3,G4 SEDAN 09/07 – 01/12
SUBARU LIBERTY MY10 SEDAN & WAGON 09/09 – ON
SUBARU OUTBACK BM,BR WAGON 09/09 – 12/14
SUBARU XV G4-X WAGON

PART NO.

UNT276

OUTBACK / XV

1. In the luggage area remove the retractable cover.
2. Remove floor cover and expose spare wheel.
3. Remove the centre rear trim.
4. The 10 way connector should be found taped to a cable running across the back rear panel. (IT HAS BEEN ADVISED THAT THE VEHICLE TOWBAR 10 WAY CONNECTOR IS NOT ALWAYS BEHIND THE CENTRE TRIM. IF THIS IS THE CASE YOU WILL NEED TO LOOK BEHIND THE R/H/S OR THE L/H/S TRIM).
5. Attach the wiring harness 10 way connector to the vehicle towbar 10 way connector.
6. Locate a grommet in the rear panel and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out the rear of the vehicle.
7. Pull the wiring harness through the grommet to meet the required length.
8. Using cable ties secure the wiring harness to meet the required length.
9. Fit the required socket to the wiring harness and mount the plug to the desired position.
10. Replace any and all trims removed.
11. Replace the floor cover.
12. Refit the retractable cover.

SUBARU FORESTER SH,SJ WAGON 03/08 – ON
SUBARU IMPREZA G3,G4 HATCH 09/07 – 01/10
SUBARU IMPREZA G3,G4 SEDAN 09/07 – 01/12
SUBARU LIBERTY MY10 SEDAN & WAGON 09/09 – ON
SUBARU OUTBACK BM,BR WAGON 09/09 – 12/14
SUBARU XV G4-X WAGON

PART NO.

UNT276

IMPREZA SEDAN & HATCH / LIBERTY SEDAN

1. Remove floor cover and expose spare wheel.
2. Remove the centre rear trim.
3. Remove the Driver side rear trim to expose the vehicle towbar wiring harness 10 way connector.
4. The 10 way connector will be found at the rear of the vehicle. it may be loose or taped to an existing vehicle cable.
5. Locate a grommet at the rear of the vehicle or in the spare wheel well.
6. Pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out the other side of the vehicle.
7. Pull the wiring harness through the grommet to meet the required length.
8. Using cable ties secure the wiring harness to meet the required length.
9. Fit the required socket to the wiring harness and mount the plug to the desired position.
10. Replace the driver side rear trim.
11. Refit the centre rear trim.
12. Replace the floor cover.

