

Towbar Wiring Harness Fitting Instructions

MITSUBISHI ASX XA WAGON 08/10 - ON

PART NO.
UNT290

Part 1 - 12 Pin Connector

- 1. In the cargo area, remove the floor carpet and parcel shelf.
- 2. Fold rear seats forward.
- 3. Remove the centre rear trim by removing the two retaining clips.
- 4. Remove drivers side panel and locate 12 pin connector.
- 5. Plug in matching 12 pin connector on supplied harness.
- 6. Mount ECU box using double sided tape provided.
- 7. Route five core cable to trailer socket mounting position. Make sure cable is securely attached using zip ties or similar (not supplied) and maintains a safe distance from heat or sharp edges.
- 8. Replace all parts removed in the reverse order as above.

Part 2 - 4 Pin Connector

- 9. Locate 4 pin connector in the engine bay. It can be found on the passenger side of the engine bay between the battery and headlight.
- Remove the blanking cap from vehicle connector and plug in to 4 pin connector on harness.
- 11. Connect the ring terminal on harness to the positive terminal on the vehicle's battery.



