

Towbar Wiring Harness Fitting Instructions

JEEP WRANGLER JK WAGON 03/07 - ON

PART NO.
UNT328

- 1. Remove LHS & RHS taillights. Remove four external screws per light.
- 2. Unplug the RHS taillight and connect the trailer wiring harness between these plugs.
- 3. Route the trailer harness across to LHS behind bumper. Make sure cable keep a safe distance from heat sources and sharp edges.
- 4. Unplug the LHS taillight and connect the trailer wiring harness between these plugs.
- 5. Route five core cable to trailer socket mounting position. Make sure cable is securely attached using zip ties or similar (not supplied) and maintains a safe distance from heat or sharp edges.
- 6. Replace all components removed in reverse from step one.

