

NISSAN NAVARA NP300 D23 UTE & CAB CHASSIS 07/15 - ON

PART NO.

UNT334

1. Locate the 8 way tail light connector on rear passenger side chassis.
2. Disconnect this 8 way connector.
3. On the Wiring Harness connect the corresponding 8 way connectors.
4. Earth the white earth terminal directly to the body of the car. (please note on some models it is hard to find a suitable body or chassis earth, it may be required to earth direct to battery).
5. Route five core cable to trailer socket mounting position. Make sure cable is securely attached using zip ties or similar (not supplied) and maintains a safe distance from heat or sharp edges.

