



Fitting Instructions: GW02H

- Vehicle:** Great Wall Cannon Ute 2020 On
- Towing Capacity:** 3000kg / 300kg
- Fitting Kit:**
- 1x 4 ½ x ½" Bolt, flat, spring washers & nut (drivers side forward hole)
 - 1x 12mm Flat washer
 - 2x 120 x 12mm Bolts, flat, spring washers & nuts (drivers side)
 - 2x 5 x ½" Bolts, flat, spring washers & nuts (pass side tie down block)
 - 2x 82mm ½" Tubes
 - 4x ½" Hole plates
 - 2x D-Shackles
 - 2x Towbar Rating Labels

1.	Remove drivers side rear 2 bumper holding bolts, (Do not remove forward most bumper holding bolt) replace with 2 x 120 x 12mm bolts.
2.	Fit 1 x 4 ½" x ½" bolt to existing hole in chassis on drivers side. Fit 2 x 5 x ½" bolts complete with ½" hole plates and crush tubes (Fit so thread of bolt faces spare wheel) to passenger side tie down block.
3.	Fit remaining 2 – ½" hole plates to bolts. (these are spacers fitted between Tow Hitch side plate and tie down block)
4.	Mount Tow hitch to vehicle – drivers side to align with bolts. Bar will then align with passenger side bolts.
5.	Fit flat washers, spring washers and nuts to all bolts and tighten.
6.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.