

FITTING INSTRUCTIONS



PART NUMBER: **T2C261**

Mitsubishi Magna & Verada Wagon 04/97 on
Towing Capacity 1500 Kg / Ball Load 90 Kg
Lug # L268

- 1) Remove towing hook on passenger side.
- 2) Lower exhaust by removing 2 x 12mm nuts holding exhaust to mount.
- 3) Remove exhaust from hangers in front of muffler.
- 4) Push exhaust down and remove two nuts holding exhaust bracket.
- 5) Remove towing hook from drivers' side.
- 6) Fit tow bar to car by lifting over exhaust and over outside of chassis rail.
- 7) On passenger side, fit 3 x M10 bolts and washers into captive nuts in chassis rail and 1 nut and washer over stud from bottom of chassis rail.
- 8) On drivers' side fit 3 x M10 bolts and washers into captive nuts on chassis rail and 1 x M10 bolt and washer into rear beaver panel.
- 9) Tighten all bolts to torque listings.
- 10) Refit exhaust mount.
- 11) Refit exhaust.
- 12) Fit tongue with bolts supplied.
- 13) Fit door sticker supplied to door.

RECOMMENDED ASSEMBLY
TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8