

FITTING INSTRUCTIONS



PART NUMBER: **T2C438**

Mitsubishi Magna Sedan 04/96 to 10/03
Towing Capacity 1000 Kg / Ball Load 80 Kg
Lug # L265

- 1) Remove bumper centre pop out.
- 2) Remove exhaust from rubbers.
- 3) Remove heat shield.
- 4) Remove bumper bar iron bolts from under chassis rail. 4 x 14mm bolts.
- 5) Remove two plastic scrivets from bottom of bumper.
- 6) Lift tow bar up to chassis rail by flexing out bottom of bumper and push tow bar up behind bumper bar and making sure that the tow bar goes over exhaust.
- 7) Fit 4 x M10 bolts through tow bar and into captive nuts welded into bumper irons.
- 8) Tighten all bolts to torque listings.
- 9) Refit heat shield.
- 10) Refit exhaust to rubbers.
- 11) Refit two plastic scrivets into bottom of bumper.
- 12) Fit tongue with bolts supplied.
- 13) Fit door sticker supplied to door.

<u>RECOMMENDED ASSEMBLY</u>	
<u>TORQUE LISTING</u>	
<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8