

FITTING INSTRUCTIONS



PART NUMBER: **T2D144**

Holden Rodeo Ute C/Chassis & S/Side 2WD 1981to 2/03
Towing Capacity 1000Kg / Ball Load 80Kg
Lug # L251

- 1) Remove towing hook if fitted.
- 2) Fit tow bar to outside of chassis rail with 2xM12 bolts, washers & nuts on each side.
- 3) Using the towbar as a guide, drill 2x 13mm holes into the side of chassis rail.
- 4) Fit 1x M12 bolt, washers & nuts for each side.
- 5) Tighten all bolts to torque listing.
- 6) Fit tongue with bolts supplied.
- 7) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8