

# FITTING INSTRUCTIONS



PART NUMBER: **T2D277**

---

Nissan Pulsar Sedan 7/03 onwards  
Towing Capacity 1000 Kg / Ball Load 100 Kg  
Lug # L231

- 1) Remove internal trim, boot mat & spare wheel.
- 2) Remove tail lights.
- 3) Remove bumper.
  - a) Remove plastic clips from under tail lights.
  - b) Remove screws & clips from wheel arch.
  - c) Remove plastic clips from bottom of bumper.
  - d) Pull bumper rearwards to unclip from body.
- 4) Remove crash cans and discard.
- 5) Remove tow hooks if fitted.
- 6) Lower exhaust.
- 7) Fit towbar to back of vehicle using 8x M8 bolts & washers into captive nuts in beaver panel.
- 8) Fit 4x M10 bolts & washers through holes in chassis rail and into welded nuts on towbar.
- 9) Using towbar as a guide, drill 2x 11mm holes into wheel well.
- 10) Fit 2x M10 bolts & plates into holes drilled from inside of boot. Fit nuts & washers from underneath.
- 11) Tighten all bolts to torque listing below.
- 12) Refit exhaust.
- 13) Refit bumper
- 14) Refit tail lights, spare wheel, boot mat and internal trim.
- 15) Fit tongue with tongue bolts supplied.
- 16) Fit door sticker supplied to door.

# FITTING INSTRUCTIONS



PART NUMBER: T2D277

---

**RECOMMENDED ASSEMBLY  
TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8