

FITTING INSTRUCTIONS



PART NUMBER: **T2D410**

Nissan Skyline Sedan R31 8/86 to 5/91
Towing Capacity 1000 Kg / Ball Load 80 Kg
Lug # L205

- 1) Fit forward arms on towbar to tow-hooks.
- 2) Swing towbar up to bottom of chassis rail and fit M10 bolt into captive nut on bottom of chassis rail.
- 3) Using towbar as guide, drill 4x 11mm holes through bottom of chassis and floor pan. (Note: Remove carpet in boot before drilling).
- 4) Open up holes in boot to allow spare tubes to be fitted. (Note: Take care not to lose them down chassis rail).
- 5) Fit plates and bolts through boot & spacer tubes.
- 6) Fit nuts & washers from underside of car.
- 7) Tighten all bolts to torque listing below.
- 8) Fit tongue with tongue bolts supplied.
- 9) Fit door sticker supplied to door.
- 10) Replace boot carpet if removed.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8