

FITTING INSTRUCTIONS



PART NUMBER: T2F443

Ford Falcon Ute Cab Chassis 07/99 – on 7'6" & 8' Tray
Towing Capacity 2300Kg / Ball Load 230Kg
Lug # L264

1. Remove exhaust from hangers.
2. Lift tow bar up to chassis rail and fit 6 x M12 bolts through tow bar and chassis rail.
3. Fit plates on outside of chassis rail with nuts and washers.
4. Fit 4 x 10mm corflex bolts into bottom of chassis rail, two each side above springs.
5. Using tow bar as a guide drill 2 x 12mm holes and fit tapped plates into chassis and fit 12mm bolts with washers.
6. Tighten all bolts to torque settings.
7. Fit tongue with bolts supplied.
8. Fit door sticker supplied to door.
9. Refit exhaust.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8