

FITTING INSTRUCTIONS



PART NUMBER: **T2F512**

Ford Focus Sedan - 05/05 on
Towing Capacity 900Kg / Ball Load 90Kg
Lug # L271

- 1) Remove bumper bar.
 - 1a) Remove tork screws from wheel arches.
 - 1b) Remove 10mm lock nut from wheel arch cavity.
 - 1c) Lift tail gate and remove 2 screws.
 - 1d) Remove two screws from under bumper.
- 2) Remove and discard impact beam.
- 3) Slide tow bar into chassis rail.
- 4) Remove tape from outside of chassis rail to expose the holes that line up with tow bar.
- 5) Fit 4 x 10mm bolts, plates and washers into welded nuts on tow bar.
- 6) Tighten all bolts to torque listing.
- 7) Refit bumper.
- 8) Fit tongue with bolts supplied.
- 9) Fit door sticker supplied to door.

**Note: 08/11 on Models required an ECU to be fitted
ECU SOLD SEPARATELY**

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>	<u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8