

FITTING INSTRUCTIONS



PART NUMBER: **T2F564**

Ford Falcon Ute FG XR6/8 only - 2009 - on
Towing Capacity 1600Kg / Ball Load 160Kg
Lug # L270C

1. Lower spare wheel.
2. Fit centre plate to rear cross member with 2 x 10mm corflex bolts. Tighten and then release slightly so bracket will move.
3. Fit tow bar to vehicle by maneuvering over spring hangers and up to chassis.
4. Fit half in bolts through chassis with washers and plates to suit but do not tighten.
5. Fit 2 x 10mm corflex bolts to either side into bottom of chassis.
6. Fit 2 x 10mm bolts into centre mount on cross member.
7. Tighten all bolts to torque settings listed below.
8. Fit tongue with bolts supplied.
9. Fit door sticker supplied to door.
10. Re fit spare wheel.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8