

# FITTING INSTRUCTIONS

PART NUMBER: **T2U055**



Suzuki Jimny 1999 - on  
Towing Capacity 750Kg / Ball Load 60Kg  
Lug # L231C

1. Slide 2 x 10mm tapped plates into chassis rail.
2. Lift tow bar and fit M16 bolt through tow hook on right hand side of vehicle with nuts and washers.
3. Fit 2 x 10mm bolts and washers into M10 tapped plates.
4. Slide M12 tapped plate into chassis rail and fit M10 bolt and washer.
5. Tighten all bolts to torque listing.
6. Fit tongue with bolts supplied.
7. Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY  
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>	<u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8