

# FITTING INSTRUCTIONS

PART NUMBER: T4D472



Nissan Patrol Wagon GQ & GU - 1988 onwards  
Towing Capacity 3500 Kg / Ball Load 350 Kg  
Lug # L4045

- 1) Remove bumper bar ends.
  - a) Remove screws and clips from wheel arches.
  - b) Unclip lights.
  - c) Remove 4x M12 bolts from behind bumper ends.
  - d) Remove 6x M8 bolts from bumper ends near centre step.
- 2) Lower exhaust.
- 3) Lift towbar up to line up with holes in chassis rail.
- 4) Fit 2x M12 bolts & washers into forward holes into tapped plates on wire.
- 5) Fit 2x M12 bolts & washers into rearward holes into tapped plates.  
(Note 13mm holes may have to be drilled into earlier models).
- 6) Fit 2x M10 bolts into tapped plates on wire. Feed into rear cross member.
- 7) Tighten all bolts to torque listing below.
- 8) Refit exhaust.
- 9) Refit bumper ends.
- 10) Fit ball mount with pin & clips supplied.
- 11) Fit door sticker supplied to door.

# FITTING INSTRUCTIONS

PART NUMBER: T4D472



RECOMMENDED ASSEMBLY  
TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>	<u>Nm</u>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8