

# FITTING INSTRUCTIONS



PART NUMBER: **T4D518**

---

Nissan X Trail 4x4 - 10/01 – 09/07  
Towing Capacity 2000 Kg / Ball Load 150 Kg  
Lug # L4180

- 1) Remove plastic under tray.
- 2) Remove 6x screws 1x behind plastic wheel arch insert, 1x on underside of bumper and 3x around wheel arch, on both sides.
- 3) Remove 3x plastic clips from under side of bumper and 2x 10mm bolts from top of bumper where the tail gate closes.
- 4) Remove bumper bar by peeling out from wheel arches.
- 5) Remove impact cones both sides.
- 6) Drop exhaust from top mount and charcoal canister out of its holder.
- 7) Fit bolts on wire to side holes in chassis rails and under side holes, offer tow bar to vehicle lining up with bolts on wire, loosely fit spring washers and nuts to all hardware.
- 8) Refit charcoal canister and exhaust to hanger.
- 9) Refit bumper bar.

**RECOMMENDED ASSEMBLY  
TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>	<b><u>Nm</u></b>
M6		9.5
M8		21.7
M10		43.4
M12		77.3
M16		189.8

# FITTING INSTRUCTIONS



PART NUMBER: T4D518

