

FITTING INSTRUCTIONS



PART NUMBER: **T4H268**

Holden Commodore Ute 1 Tonne VY Cab Chassis

06/03 to 12/06

Towing Capacity 2100Kg / Ball Load 210Kg

Lug # L4180

- 1) Fit tow bar to vehicle using 2 x 12 x 1.5 mm bolts and washers into bottom of chassis rail.
- 2) Fit 2 x tapped plate on wire through side of chassis rail and fit 2 x ½ inch bolts and washers.
- 3) Fit 2 x ½ inch bolts and nuts into rear of chassis rail, through tow bar.
- 4) Tighten all bolts to torque settings.
- 5) Fit ball mount with pin and clip supplied.
- 6) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8