

FITTING INSTRUCTIONS



PART NUMBER: T4H592

Holden Colorado Ute C/Chassis & S/Side

No step 6/12 onwards

Towing Capacity 3500 Kg / Ball Load 350 Kg

Lug # L4045

- 1) Remove shipping hook.
- 2) Fit towbar to outside of chassis rail using 6x M12 bolts & washers into captive nuts.
- 3) Fit 2x M12 bolts & plates through bottom of chassis and through towbar on rear holes. Fit nuts & washers from underneath.
- 4) Slide bolt & plate on wire down chassis into forward HOLE IN TOWBAR. Fit nuts & washers from underneath.
- 5) Tighten all bolts to torque listing below.
- 6) Fit ball mount with pin & clip supplied.
- 7) Fit door sticker supplied to door.

**ECU MUST BE FITTED WITH THIS TOWBAR
ECU SOLD SEPARATELY**

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8