

FITTING INSTRUCTIONS



PART NUMBER: **T4M471**

Mazda BT50 Style Side with Chrome Step 11/06 to 08/11 Towing Capacity 1600 Kg / Ball Load 85Kg Lug # L4045

- 1) Lower spare wheel.
- 2) Remove rear step and discard the genuine mounting brackets.
- 3) Fit tow bar to vehicle using 4 x M12 x 1.5 bolts and washers into side of chassis rail.
- 4) Fit bolt on wire down chassis rail and protrude out through forward most hole in tow bar.
- 5) Fit nuts and washers.
- 6) Fit tow bar step mounts to step.
- 7) Fit step and mounts to tow bar using 4 x M10 bolts, nuts and washers.
- 8) Tighten all bolts to torque settings.
- 9) Refit spare wheel.
- 10) Fit ball mount with pin and clip supplied.
- 11) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8