

FITTING INSTRUCTIONS



PART NUMBER: **T4P499**

Jeep Cherokee KK 03/08 onwards
Towing Capacity 2250Kg / Ball Load 220Kg
Lug # L4180

- 1) Remove shipping hook.
- 2) Fit towbar to vehicle using 6x M12 bolts & washers into captive nuts and into bottom of chassis rail.
- 3) Tighten all bolts to torque listing below.
- 4) Fit ball mount with pin & clip supplied.
- 5) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY
TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8