

FITTING INSTRUCTIONS



PART NUMBER: T4T507

Toyota Kluger 08/07 – on
Towing Capacity 2000 Kg / Ball Load 200 Kg
Lug # L4120

- 1) Remove plastic step guards from underside of bumper.
- 2) Remove shipping hooks from chassis.
- 3) Lift tow bar on to chassis rail and fit M10 x 1.25 bolts in to captive nuts on side of chassis and bottom of chassis.
- 4) Fit ½ inch x 1 ¾ bolts through rear beaver panel.
- 5) Tighten all bolts to torque list below.
- 6) Refit plastic splash guards and trim to suit if required.
- 7) Fit ball mount with pin and clip supplied.
- 8) Fit door sticker supplied to door.

ECU MUST BE FITTED WITH THIS TOWBAR

ECU SOLD SEPARATELY

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8