

# FITTING INSTRUCTIONS



PART NUMBER: **T9T008**

---

Hiace SLWB Commuter Bus 05/05 - on  
Towing Capacity 1250 Kg / Ball Load 100 Kg  
Lug # L237

- 1) Remove shipping hooks
- 2) Remove 2 x 12mm most rearward bolts holding spare wheel brace and discard.
- 3) Fit tail light protector to chassis rail via 6 x 12mm bolts and washers.
- 4) Tighten all bolts to torque listing.
- 5) Fit tongue with bolts supplied.
- 6) Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY TORQUE**  
**LISTING**

<b><u>Diameter</u></b> <b><u>Bolt</u></b>	<b><u>Grade 8.8</u></b> <b><u>Nm</u></b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8