

# FITTING INSTRUCTIONS



Toyota Corolla Hatch/Sedan(05/07-09/12)– T2T467

<b>Max Towing Capacity:</b> 1120kg	<b>Towbar Weight:</b> 16kg
<b>Max Ball Load:</b> 95kg	<b>Wiring Harness Part #:</b> UNT273



## Tools Required:

- Spanners, Sockets, Torque Wrench

Kit Contents					
Item No.	Description	Qty	Item No.	Description	Qty
1.	Towbar – T2T467	1	6.	M16 x 2 x 40 Bolt	2
2.	Ball Mount – L233c	1	7.	M16 Spring washer	2
3.	M12 x 1.25 x 35 Bolt	6	8.	Ratings Sticker	1
4.	M12 Shake proof washer	6			
5.	M12 Flat Washer	6			

## Warning:

- This product is for towing purposes only and must only be loaded as shown in your vehicle Owners Manual.
- This towbar is NOT to be drilled, cut, welded or modified in any way.
- Check behind chassis rail and body panels before drilling to ensure no hazards are present

## General:

- Before fitting this towbar read fitting instructions and check installation hardware is correct.
- Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.
- After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.
- If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change. If you are not sure, then please ask your towbar supplier

# FITTING INSTRUCTIONS

Toyota Corolla Hatch/Sedan(05/07-09/12)– T2T467



<b>Step 1   Preparing for Fitment</b>		
<b>Instructions</b>	<b>Tools</b>	<b>Torque Spec</b>
a. Remove all bolts from towbar taking note of locations. b. <b>On hatch models only;</b> Undo bolt for fuel filler pipe on passenger side.	Spanners	N/A

<b>Step 2   Towbar Fitment</b>		
<b>Instructions</b>	<b>Tools</b>	<b>Torque Spec</b>
a. Fit towbar onto vehicle securing with M12 Bolts and Washers supplied. b. For hatch models place towbar over fuel filler pipe. c. Tighten all bolts to specified ratings.	Spanners Sockets Torque Wrench	M12-103Nm

<b>Step 3   Finishing Up</b>		
<b>Instructions</b>	<b>Tools</b>	<b>Torque Spec</b>
a. Reattach fuel filler pipe. b. Fit ball mount using M16 bolts and washers supplied and tighten with a torque wrench. c. Attach ratings sticker to drivers side door pillar.	Spanners Sockets Torque Wrench	M16-270Nm

# FITTING INSTRUCTIONS

Toyota Corolla Hatch/Sedan(05/07-09/12)– T2T467



## WARRANTY STATEMENT

The manufacturer of TAG branded products, warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us directly by email at [warranty@tagtowing.com](mailto:warranty@tagtowing.com)