

Toyota Prado 120/150 series – T4T482

Max Towing Capacity: 3000kg	Towbar Weight: N/A
Max Ball Load: 300kg	Wiring Harness Part #: UNT282



Tools Required:

- Spanners, Sockets, Torque Wrench

Kit Contents					
Item No.	Description	Qty	Item No.	Description	Qty
1.	Towbar	1	9.	1/2" x 1 ¾" Bolt	2
2.	Ball mount- L4045	1	10.	½" Shake proof washer	2
3.	M12 x 1.25 x 35 Bolt	4	11.	½" Flat washer	2
4.	M12 Shake proof washer	4	12.	½" Nut with wire	
5.	M12 Flat washer	4	13.	Top plate 40mm x 40mm 14mm hole	2
6.	M10 x 1.5 x 30 Bolt	2	14.	Class 4 Pin	2
7.	M10 Shake proof washer	2	15.	Label	1
8.	Plate with wire and M10 x 1.5 Thread	2			1



Warning:

- This product is for towing purposes only and must only be loaded as shown in your vehicle Owners Manual.
- This towbar is NOT to be drilled, cut, welded or modified in any way.
- Check behind chassis rail and body panels before drilling to ensure no hazards are present

General:

- Before fitting this towbar read fitting instructions and check installation hardware is correct.
- Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.



Toyota Prado 120/150 series – T4T482

- After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.
- If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change. If you are not sure, then please ask your towbar supplier

T4T482 Rev 1



Toyota Prado 120/150 series – T4T482

Step 1			
Instructions	Tools	Torque Spec	
a. Remove towing hook b. Remove exhaust from hangers	Spanners	N/A	

Step 2		
Instructions	Tools	Torque Spec
 a. Fit towbar to bottom of chassis rail via 4 x M12 x 1.25 bolts and washers into captive nuts in chassis rail 	Spanners	N/A
 b. Fit nut on wire into cross member and fit m12 bolts and washers through centre mounts on towbar. Note: Use spacer plates provided on Prado 150 series 		

Step 3 Install Towbar			
Instructions	Tools	Torque Spec	
a. Using Towbar as a guide drill 2 x 13mm holes	Drill	N/A	
into chassis rail.	Spanners		
b. Using access hole in chassis rail near rear			
wheel slide bolt on wire into chassis rail, down			
into drilled hole			
c. Fit nuts and washers			

Step 4	Cut Bumper Bar		
		1	
Instructions	s	Tools	Torque Spec
a. Tighten	all bolts with Torque wrench	Torque Wrench	M10- 77Nm
b. Refit Exh	naust	Spanners	UNC ½ -
c. Fit ball n	nount with pin and clip supplied		125Nm
d. Fit door	sticker to drivers side door jam		

T4T482 Rev 1



Toyota Prado 120/150 series – T4T482



WARRANTY STATEMENT

The manufacturer of TAG branded products, warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us directly by email at warranty@tagtowing.com

T4T482 Rev 1